

ALGER EQUIPMENT CO., INC.

320 Flightline

Lago Vista, TX 78645

Phone: 512-267-0383

FAX: 512-267-0452

TOLL FREE: 800-320-1043

ALGER-LITE LOW VOLTAGE INSTALLATION

1. Install ALGER-LITE cabinet on ceiling as per other instructions.

**** **Caution** ****

Do NOT lift ALGER-LITE by lite bar or put any undue force on lite bar as motor gears will be destroyed!!

2. Attach low voltage box to top of ALGER-LITE and hook up wires from ALGER-LITE to low voltage box as per diagram.

3. Run the 4 ea. low voltage wires to the control switches from the low voltage box as shown.

4. Connect 110V. input as shown.

5. If you are using the ALGER-LITE footswitch in conjunction with this low voltage option do not hook up the "GREEN" wire coming from the footswitch -- only 4 wires are necessary.

